

Alphabetical index

Alphabetical index

| | | | | |
|----------|--------------------------------------|--------|-------------------------------------|-----|
| A | A/C | 192 | Alarm..... | 74 |
| | ABS..... | 170 | Antenna..... | 208 |
| | AFS | 144 | Anti-lock brake system..... | 170 |
| | Adaptive front lighting system | 144 | Armrest | 255 |
| | Air conditioning filter | 322 | Ashtrays..... | 248 |
| | Air conditioning system | | Audio input..... | 228 |
| | Air conditioning filter | 322 | Audio system | |
| | Automatic air conditioning | | Antenna..... | 208 |
| | system..... | 192 | Audio input..... | 228 |
| | Airbags | | AUX adapter | 228 |
| | Airbag operating conditions..... | 81 | CD player/changer | 211 |
| | Airbag precautions for your | | MP3/WMA disc..... | 217 |
| | child..... | 85 | Optimal use | 225 |
| | Airbag warning light | 361 | Portable music player | 228 |
| | Curtain shield airbag operating | | Radio | 204 |
| | conditions..... | 82 | Steering wheel audio switch..... | 229 |
| | Curtain shield airbag | | Automatic air conditioning | |
| | precautions | 85 | system | 192 |
| | Front passenger occupant | | Automatic headlight leveling | |
| | classification system..... | 90 | system | 145 |
| | General airbag precautions | 85 | Automatic light control system..... | 143 |
| | Locations of airbags..... | 79 | Automatic transmission | |
| | Modification and disposal of | | Automatic transmission | 122 |
| | airbags..... | 89 | If the shift lever cannot be | |
| | Proper driving posture | 77, 85 | shifted from P..... | 392 |
| | Side airbag operating | | S mode | 124 |
| | conditions..... | 82 | AUX adapter | 228 |
| | Side airbag precautions | 85 | | |
| | SRS airbags | 79 | | |

B

| | |
|--|------------|
| Back-up lights | |
| Wattage | 420 |
| Battery | |
| Checking | 302 |
| If the vehicle has discharged battery | 397 |
| Preparing and checking before winter | 183 |
| Bottle holders | 241 |
| Brake | |
| Fluid | 301 |
| Parking brake | 129 |
| Brake assist | 170 |

C

| | |
|---------------------------------------|------------|
| Care | |
| Exterior | 274 |
| Interior | 277 |
| Seat belts | 278 |
| Cargo capacity | 179 |
| Cargo hooks | 261 |
| CD changer | 211 |
| CD player | 211 |
| Chains | 183 |
| Child restraint system | |
| Booster seats, definition | 95 |
| Booster seats, installation | 99 |
| Convertible seats, definition | 95 |
| Convertible seats, installation | 99 |

| | |
|---|------------|
| Front passenger occupant classification system | 90 |
| Infant seats, definition | 95 |
| Infant seats, installation | 99 |
| Installing CRS with lower anchorage | 102 |
| Installing CRS with seat belts | 99 |
| Installing CRS with top straps | 103 |
| Child safety | |
| Airbag precautions | 85 |
| Battery precautions | 304, 399 |
| Child restraint system | 95 |
| Child-protectors | 38 |
| How your child should wear the seat belt | 55 |
| Installing child restraints | 98 |
| Moon roof precautions | 68 |
| Power window lock switch | 64 |
| Power window precautions | 65 |
| Removed electronic key battery precautions | 326 |
| Seat belt comfort guide | 53 |
| Seat belt extender precautions | 57 |
| Seat belt precautions | 56 |
| Seat heater precautions | 252, 254 |
| Trunk precautions | 43 |
| Child-protectors | 38 |
| Cigarette lighter | 249 |

Cleaning
 Exterior274
 Interior277
 Seat belts.....278
Clock244
Coat hooks.....259
Compass269
Condenser301
Console box237
Cooling system
 Engine overheating 400
Cornering assist sensors 164
Cruise control
 Cruise control152
 Dynamic radar cruise control 155
Cup holder239
Curtain shield airbags..... 79
Customizable features436

D Daytime running light system.....144
Defogger
 Rear window200
 Side mirror200
Dimension406
Dinghy towing.....188, 189
Display
 Dynamic radar cruise control.....155
 Satellite switch mode..... 245
 Trip information.....140
 Warning message369
Do-it-yourself maintenance286
Door courtesy lights
 Door courtesy lights..... 231
 Wattage 420
Door pockets241
Doors
 Door glasses.....64
 Door lock22, 34, 37
 Side mirrors..... 61
Driver's seat belt reminder light..... 362
Driving
 Correct posture.....77
 Procedures.....108
Driving position memory..... 46

| | | |
|----------|--|-----|
| E | Electric power steering | 170 |
| | Electronic key | |
| | If the electronic key does not operate properly | 394 |
| | Emergency, in case of | |
| | If the engine will not start | 391 |
| | If the shift lever cannot be shifted from P | 392 |
| | If the vehicle has discharged battery | 397 |
| | If the warning buzzer sounds | 360 |
| | If the warning light turns on | 360 |
| | If the warning message is displayed | 369 |
| | If you have a flat tire | 382 |
| | If you lose your keys | 393 |
| | If you think something is wrong | 356 |
| | If the electronic key does not operate properly | 394 |
| | If your vehicle becomes stuck | 402 |
| | If your vehicle needs to be towed | 350 |
| | If your vehicle overheats | 400 |

| | |
|---|-----|
| Engine | |
| Compartment | 292 |
| Engine switch | 117 |
| Hood | 289 |
| How to start the engine | 117 |
| Identification number | 407 |
| If the engine will not start | 391 |
| Ignition switch | 117 |
| Overheating | 400 |
| Engine compartment cover | 294 |
| Engine coolant | |
| Capacity | 411 |
| Checking | 299 |
| Preparing and checking before winter | 183 |
| Engine coolant temperature gauge | 130 |
| Engine immobilizer system | 72 |
| Engine oil | |
| Capacity | 410 |
| Checking | 295 |
| Preparing and checking before winter | 183 |
| Engine oil maintenance data | 298 |
| EPS | 170 |
| Event data recorder | 358 |

F First-aid kit storage belt 261
Floor mat260
Fluid
 Brake..... 301
 Washer305
Fog lights
 Switch146
 Wattage.....420
Foot well lighting 231
Front fog lights
 Switch146
 Wattage.....420
Front passenger occupant
 classification system 90
Front passenger's seat belt
 reminder light.....362
Front seats
 Adjustment..... 44
 Driving position memory..... 46
 Seat position memory 49

Front turn signal lights
 Switch.....128
 Wattage 420
Fuel
 Capacity 409
 Fuel gauge.....130
 Fuel pump shut off system.....357
 Gas station information 464
 Information 421
 Refueling.....69
Fuel door 69
Fuel filler door 69
Fuel pump shut off system..... 357
Fuses..... 327

G Garage door opener 264
Gas station information 464
Gauges130
Glove box..... 236
Glove box light 237

| | | |
|----------|---------------------------------|----------|
| H | Head restraints | |
| | Adjusting | 51 |
| | Headlight aim | 341 |
| | Headlight cleaner | 151 |
| | Headlights | |
| | Discharge headlights | |
| | precautions | 348 |
| | Replacing light bulbs | 342 |
| | Switch | 143 |
| | Wattage | 420 |
| | Heaters | |
| | Seat heaters | 251, 253 |
| | Side mirror | 200 |
| | Hill-start assist control | 170 |
| | Hood | 289 |
| | Hooks | |
| | Cargo | 261 |
| | Coat | 259 |
| | Shopping bag | 261 |

| | | |
|----------|--------------------------------|-----|
| I | I/M test | 285 |
| | Identification | |
| | Engine | 407 |
| | Vehicle | 407 |
| | Ignition switch | 117 |
| | Illuminated entry system | 233 |
| | Indicator lights | 136 |
| | Initialization | |
| | Items to initialize | 441 |
| | Inside rear view mirror | 60 |
| | Interior lights | |
| | Interior lights | 231 |
| | Switch | 234 |
| | Wattage | 420 |
| J | Jack | |
| | Positioning a floor jack | 290 |
| | Replacing the wheel | 382 |
| | Jack handle | 382 |

K Keyless entry.....34

Keys

- Electronic key.....20
- Engine switch.....117
- If you lose your keys.....393
- If the electronic key does not
operate properly394
- Key number20
- Keyless entry34
- Keys20
- Mechanical key.....20
- Wireless remote control key.....34

L Light bulbs

- Replacing.....342
- Wattage.....420

Lights

- Door courtesy lights.....231
- Fog light switch.....146
- Headlights switch.....143
- Interior light switch.....234
- Outer foot lights.....231
- Overhead courtesy light.....231
- Personal light switch234
- Replacing light bulbs.....342
- Scuff lighting.....231
- Shift lever lighting231
- Turn signal lever.....128
- Vanity lights243
- Wattage.....420

Load capacity.....182

M Maintenance

- Do-it-yourself maintenance.....286
- General maintenance.....282
- Maintenance data406
- Maintenance requirements.....280

Manual transmission126

Meter

- Instrument panel light control.....131
- Meters.....130

Micro dust and pollen filter196

Mirrors

- Inside rear view mirror60
- Side mirror heater.....200
- Side mirrors.....61
- Vanity mirrors243

Moon roof.....66

MP3 disc.....217

Multi-information display139

O Odometer130

Oil

- Engine oil.....295

Opener

- Fuel filler door69
- Hood289
- Trunk.....41

Outer foot lights

- Outer foot lights.....231
- Wattage420

Outside rear view mirrors

- Adjusting and folding61
- Mirror position memory.....46

Outside temperature display140

Overhead console.....238

| | |
|--------------------------------|-----|
| Overhead courtesy lights | |
| Overhead courtesy lights | 231 |
| Wattage | 420 |
| Overheating, Engine | 400 |

| | | |
|----------|------------------------------|-----|
| P | Parking assist sensors | 164 |
| | Parking brake | 129 |
| | Parking lights | |
| | Replacing light bulbs | 342 |
| | Switch | 143 |
| | Wattage | 420 |
| | PCS | 176 |
| | Personal lights | |
| | Switch | 234 |
| | Power outlet | 250 |
| | Power windows | 64 |
| | Pre-collision system | 176 |

| | | |
|----------|------------------------------|-----|
| R | Radar cruise control | 155 |
| | Radiator | 301 |
| | Radio | 204 |
| | RDS | 205 |
| | Rear sunshade | 256 |
| | Rear turn signal lights | |
| | Replacing light bulbs | 342 |
| | Wattage | 420 |
| | Rear view mirror | |
| | Compass | 269 |
| | Rear window defogger | 200 |
| | Replacing | |
| | Electronic key battery | 325 |
| | Fuses | 327 |
| | Light bulbs | 342 |
| | Reporting safety defects for | |
| | U.S. owners | 444 |

| | | |
|----------|-------------------------------------|----------|
| S | Scuff lighting | 231 |
| | Seat belts | |
| | Adjusting the seat belt | 53 |
| | Automatic locking retractor | 54 |
| | Child restraint system | |
| | installation | 98 |
| | Cleaning and maintaining | |
| | the seat belts | 278 |
| | Emergency locking retractor | 54 |
| | How to wear your seat belt | 52 |
| | How your child should wear | |
| | the seat belt | 55 |
| | Pregnant women, | |
| | proper seat belt use | 54 |
| | Reminder light | 362 |
| | Seat belt extenders | 55 |
| | Seat belt pretensioners | 53 |
| | Seat heaters | 251, 253 |
| | Seat position memory | 49 |
| | Seat ventilators | 253 |
| | Seating capacity | 182 |
| | Seats | |
| | Adjustment | 44 |
| | Adjustment precautions | 45 |
| | Child seats/child restraint | |
| | system installation | 98 |
| | Cleaning | 277 |
| | Driver's seat position memory | 46 |
| | Front passenger seat position | |
| | memory | 49 |
| | Head restraint | 51 |
| | Properly sitting in the seat | 77 |
| | Seat heaters | 251, 253 |
| | Ventilated seats | 253 |
| | Service reminder indicators | 136 |

Shift lever

| | |
|--|-----|
| Automatic transmission..... | 122 |
| If the shift lever cannot be shifted from P | 392 |
| Manual transmission | 126 |

Shift lever lighting 231

Shift lock system.....392

Shopping bag hooks..... 261

Side airbags.....79

Side marker lights

| | |
|--------------|-----|
| Switch | 143 |
|--------------|-----|

Side mirror

| | |
|------------------------------|----|
| Adjusting and folding | 61 |
| Mirror position memory | 46 |

Smart access system with

push-button start

| | |
|--------------------------|-----|
| Entry function..... | 22 |
| Starting the engine..... | 117 |

Spare tire

| | |
|-------------------------|-----|
| Inflation pressure..... | 316 |
| Spare tire..... | 382 |

Spark plug.....411

Specifications406

Speech command switch*

Speedometer

| | |
|-----------------------|-----|
| Speed indicator | 130 |
| Speedometer | 130 |

Steering wheel

| | |
|---|-----|
| Audio switches..... | 229 |
| Manual adjustment..... | 58 |
| Power adjustment..... | 59 |
| Steering wheel position memory | 46 |

Storage feature 236

Stuck

| | |
|------------------------------------|-----|
| If your vehicle becomes stuck | 402 |
|------------------------------------|-----|

Sun visors..... 242

Sunshade

| | |
|------------|-----|
| Rear | 256 |
| Roof..... | 67 |

Switch

| | |
|-----------------------------------|-----|
| ECT switch..... | 123 |
| Engine switch | 117 |
| ETCS switch..... | 126 |
| Fog light switch | 146 |
| Ignition switch | 117 |
| Light switches..... | 143 |
| Power door lock switch..... | 37 |
| Power window switch | 64 |
| Satellite switches..... | 245 |
| Transmission shift switches | 124 |
| Window lock switch..... | 64 |
| Wipers and washer switch..... | 147 |

T

Tachometer

- Tacho indicator130
- Tachometer130

Tail lights

- Switch143

Talk switch*

Telephone switch*

Theft deterrent system

- Alarm74
- Engine immobilizer system72

Theft prevention labels76

Tire inflation pressure316

Tire information

- Glossary429
- Size426
- Tire identification number426
- Uniform tire quality grading427

Tires

- Chains183
- Checking306
- If you have a flat tire382
- Inflation pressure316
- Inflation pressure sensor308
- Information424
- Replacing382
- Rotating tires306
- Size415
- Snow tires183

Tools382

Total load capacity182

Towing

- Dinghy towing188, 189
- Emergency towing350
- Trailer towing187

TRAC170

Traction control170

Transmission shift switches124

Trip meter130

Trunk

- Extending a space258
- Opener41

Trunk light

- Trunk light42
- Wattage420

Turn signal lights

- Replacing light bulbs342
- Switch128
- Wattage420

*: Refer to the "Navigation System Owner's Manual"

V

Vanity lights

| | |
|---------------------|-----|
| Vanity lights | 243 |
| Wattage..... | 420 |

Vanity mirrors243

VDIM..... 170

Vehicle dynamics integrated

| | |
|------------------|-----|
| management | 170 |
|------------------|-----|

Vehicle identification number407

Vehicle stability control..... 170

Ventilators253

VSC..... 170

W

Warning buzzers

| | |
|-------------------------|-----|
| Brake system | 360 |
| Open door | 362 |
| Seat belt reminder..... | 362 |

Warning lights

| | |
|---------------------------------|-----|
| Anti-lock brake system..... | 361 |
| Brake assist system..... | 361 |
| Brake system | 360 |
| Charging system | 361 |
| Electric power steering | |
| warning light..... | 361 |
| Low fuel level..... | 362 |
| Malfunction indicator lamp..... | 361 |
| Master warning light | 362 |
| Open door | 362 |
| Pre-collision system..... | 361 |
| Pretensioners..... | 361 |
| Seat belt reminder light | 362 |
| SRS airbags | 361 |
| Tire pressure warning | |
| light..... | 362 |

Warning messages

| | |
|---------------------------------|----------|
| AWD system..... | 370 |
| Dynamic radar | |
| cruise control..... | 370, 373 |
| Engine oil level..... | 373 |
| Engine oil maintenance..... | 373 |
| Engine oil pressure..... | 369 |
| Hill-start assist control | 372 |
| Hood..... | 373 |
| Intuitive parking assist..... | 370, 373 |
| Moon roof..... | 373 |
| Open door..... | 373 |
| Parking brake..... | 373 |
| Pre-collision system..... | 370, 373 |
| Smart access system with | |
| push-button start | 378 |
| Steering lock..... | 370 |
| Tire pressure | |
| warning system..... | 370, 373 |
| Traction control..... | 372 |
| Trunk..... | 373 |
| Vehicle stability control..... | 372 |
| Washer fluid | 373 |

Washer

| | |
|------------------------|-----|
| Checking..... | 305 |
| Preparing and checking | |
| before winter..... | 183 |
| Switch..... | 147 |

Washing and waxing.....274

Weight

| | |
|----------------------|-----|
| Cargo capacity | 179 |
| Load limits..... | 182 |
| Weight..... | 406 |

| | |
|-----------------------------|-----|
| Wheels | 320 |
| Window glasses | 64 |
| Window lock switch..... | 64 |
| Windows | |
| Power windows | 64 |
| Rear window defogger | 200 |
| Washer..... | 147 |
| Windshield wipers | 147 |
| Wireless remote control key | |
| Replacing the battery | 325 |
| WMA disc..... | 217 |